

Kinesis

Freestyle2 Keyboard Accessories

Further adapt the Kinesis keyboard

Additional accessories are available to provide additional keyboard configurations.

Freestyle V3 Accessory

Product Code: AC730-BLK



Add the optional V3 accessory to the Freestyle2 to create tenting of the keyboard halves by 5°, 10° or 15°. The V3 accessory cannot be used in conjunction with the palm supports.

Freestyle 2 Palm Supports

Product Code: AC806PS-BLK



Palm supports come as part of the VIP3 accessory or can be added as an accessory by themselves. They cannot, however, be attached to the V3 accessory.

Freestyle 2 VIP3 Accessory

Product Code: AC820-BLK



Create adjustable lateral sloping or tenting of the keyboard modules at 5°, 10° or 15°. Palm supports are included with this kit and must be attached in order to use the tenting mechanism.

Kinesis Freestyle 2 Numeric Keypad

Product Code: AC800HPB-us



A discrete numeric keypad, the Freestyle2 keypad seamlessly matches the low-profile design of the Freestyle2 keyboard. Includes a 2 port USB hub and embedded hot keys “Cut”, “Copy” & “Paste”.